

FISHER & PAYKEL

**INTEGRATED
REFRIGERATOR & FREEZER**

INTEGRATED REFRIGERATOR FREEZER

RS2474B models

INTEGRATED REFRIGERATOR

RS2474S3 models

INTEGRATED FREEZER

RS2474F3 models

USER GUIDE

US CA

CONTENTS

| | |
|---------------------------|----|
| Safety and warnings | 5 |
| Before you begin | 10 |
| Control panel | 12 |
| Food modes | 13 |
| Features | 14 |
| Settings | 15 |
| Wi-Fi connection | 16 |
| Adjusting the temperature | 17 |
| Food mode presets | 18 |
| Changing features | 19 |
| Changing settings | 20 |
| Water dispenser | 21 |
| Ice maker | 22 |
| Storage features | 23 |
| Care and cleaning | 24 |
| Food care | 28 |
| User warnings and sounds | 29 |
| Troubleshooting | 30 |
| Service & warranty | 33 |

Registration

To register your product visit our website: fisherpaykel.com/register

⚠ WARNING!



Electric Shock Hazard

Failure to do so can result in death, electric shock, fire or injury to persons.

- Read and follow the safety and warnings outlined in this user guide before operating this appliance.

⚠ WARNING!



This appliance contains flammable refrigerant isobutane (R600a).

READ AND SAVE THIS GUIDE

WARNING!

Read entire manual. Failure to follow all guides and rules could cause personal injury or property damage. When using this appliance, always exercise basic safety precautions including the following:

General Use

- This product has been designed for use in a normal domestic (residential) environment.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be undertaken by children without supervision.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- The manufacturer's installation instructions for product and cabinetry ventilation must be followed when installing the appliance.
- To avoid hazard due to instability of the appliance, it must be fixed in accordance with installation instructions.
- Keep ventilation openings, in the appliance enclosure or the built-in structure, clear of obstruction.
- Do not use mechanical devices or other means to accelerate the defrosting process, other than those recommended by the manufacturer.
- Do not damage the refrigerant circuit.
- In case of damage to the refrigerant circuit, ventilate the area by opening all windows.
- Do not operate electrical equipment or any other equipment that may produce arcs, sparks or flames in the area. Contact your Fisher & Paykel trained and supported service technician immediately to arrange for the appliance to be repaired.
- Connect to potable water supply only.

SAFETY AND WARNINGS

- This refrigerating appliance is intended to be used at ambient temperatures ranging from 61 °F (16 °C) to 100 °F (38 °C). The product performance may be compromised when operating outside of this temperature range.
- For storage of general household foods in the most efficient manner, it is recommended to use the product in the factory configuration supplied. Moving the shelves and bins will have a minimal impact on efficiency.
- It is hazardous for anyone other than a Fisher & Paykel trained and supported service technician to service this appliance.
- Ensure the installer has completed the final checklist in the installation guide.

Electrical

- This appliance must be installed in accordance with the installation instructions before use.
- To allow disconnection of the appliance from the supply after installation, incorporate a switch in the fixed wiring in accordance with the wiring rules.
- Never unplug your refrigerator by pulling on the power cord. Always grip the plug firmly and pull straight out from the outlet.
- Do not plug in any other appliance at the same power point as your refrigerator or use extension cords or double adapters.
- Repair or replace immediately all electric service cords that have become frayed or otherwise damaged. Do not use a cord that shows cracks or abrasion along its length or at either the plug or appliance end.
- If the power supply cord is damaged, it must only be replaced by your Fisher & Paykel trained and supported service technician because special purpose tools are required. When moving your appliance away from the wall, be careful not to roll over or damage the power cord.
- **WARNING:** Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- When positioning the appliance, ensure the power cord is not trapped or damaged.
- Do not locate multiple portable socket-outlets or portable power supplies at the rear of the appliance.

Food safety

- Regularly clean accessible draining systems and surfaces that come in contact with food.
- Ensure any raw meat or fish is stored in sealed containers to prevent cross-contamination.
- Immediately clean any drips or spills on surfaces.
- If the appliance will be left empty for long periods, switch off, defrost, clean, dry, and leave the door open to prevent mould developing within the appliance.
- Opening the door for long periods can cause a significant increase of the temperature in the compartments of the appliance.

Storing food and drinks/wine

- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Never store volatile or flammable materials in your appliance as they may explode.
- Never freeze liquids in glass containers. Liquid expands during freezing, which may cause the container to explode.
- Never freeze carbonated drinks. They may explode.

SAFETY AND WARNINGS

Servicing

- Your refrigerator is designed to operate for many years without the need for service checks. However, if your refrigerator is malfunctioning, have it attended to by your Fisher & Paykel trained and supported service technician as soon as possible. All electrical repairs must be carried out by an adequately trained service technician or qualified electrician.
- The LED light cannot be serviced by the user. Contact your Fisher & Paykel Dealer or Fisher & Paykel trained and supported service technician.
- If you suspect that the product is not getting cold—items such as ice cream are melting—remove all perishable food and store in another appliance or cooler to prevent spoilage. Immediately call for a service technician.

Cleaning

- Use mild dish-washing liquid with warm water and a lint-free cloth to clean the product.
- Avoid using anti-bacterial cleaning products on either the interior or exterior of the cabinet as they may cause rusting of metal components and cracking of plastic components.

Disposal

- Extreme care must be taken when disposing of your old appliance to avoid hazards:
- The flammable refrigerant gas must be safely removed by a qualified service technician.
- The thermal insulation foam in this appliance may contain flammable insulation blowing gases, any exposed foam may be highly flammable and must be carefully treated during disposal.
- **WARNING:** Risk of child entrapment. Before you throw away your old refrigerator or freezer, the doors and panels should be removed and the racks left in place so that children may not easily climb inside.
- Consult your local energy authority or local codes as to the best way to dispose of your old appliance.
- Remove all packaging and dispose of it responsibly. Recycle items that you can.

Water connection

- The water connection to your Ice & water refrigerator must be installed by an authorised plumber or Fisher & Paykel trained and supported service technician.
- Installation and use **MUST** comply with all state and local plumbing codes. Check with your local public works department for plumbing codes. You must follow their guidelines as you install the water filtration system.
- If the water tank has not been used for an extended period of time, or has developed an unpleasant taste or odour, flush the water system. If the problem persists, replace the water filter cartridge. For more information go to fisherpaykel.com/water-filter.
- To avoid serious illness or death, only connect your water filter to safe drinking water.
- The water filter cartridge needs to be changed when the replacement indicator icon illuminates. This will happen every six months.
- If the water filtration system has been allowed to freeze, replace filter cartridge. Failure to replace the disposable filter at recommended intervals may lead to reduced filter performance and failure of the filter, causing property damage from water leakage or flooding.
- In cases of excessively reduced filter life — we recommend that you consult a local plumber or your water supplier for advice on suitable filtration requirements for the water supplied to your home.

SAFETY AND WARNINGS

- Filter replacement is the consumer's responsibility and will not be covered by the warranty except in the case of faulty parts or materials within the filter cartridge.
- If the water has not created ice for some time or ice has an unpleasant taste or odour dispose of ice and flush the water system. If unpleasant taste or odour persists, replace the water filter cartridge. For more information go to fisherpaykel.com/water-filter.
- Use new tubing supplied with the refrigerator. DO NOT reuse old tubing from old water and ice connections.
- Your water filtration system can withstand up to 120psi (827kPa) of water pressure.
- If a pressure limiting valve is supplied, ensure that it is installed before installing the water filtration system. DO NOT install if water pressure exceeds 120psi (827kPa).

To reduce the risk associated with property damage due to water leakage or flooding:

- DO NOT install systems in areas where ambient temperatures may go above 100°F (38°C) or drop below 33°F (0.6°C).
- DO NOT install on hot water supply lines. The maximum operating water temperature of this filter system is 100°F (38°C).
- DO NOT install where water hammer conditions may occur. If water hammer conditions exist, you must install a water hammer arrester.

WARNING!

To reduce the risk associated with choking:

- DO NOT allow children under 3 years of age to have access to small parts during the installation of the water filter.

Ice making

- Avoid contact with the moving parts of the ice maker ejector mechanism, and do not place your fingers on the automatic ice-making mechanism while the appliance is in operation.
- At first use or after water filter has been replaced, there may be discolouration in the first bin of ice cubes. Discard the discoloured ice cubes. If discolouration continues in succeeding bins, contact your Fisher & Paykel trained and supported service technician

Power failure

- In the event of a power interruption, the appliance will automatically save the current temperature settings. When power is recovered, the appliance will revert to the current temperature settings only.
- Most power failures are corrected within a short period of time. 1-2 hours loss of power will not affect the appliance's temperatures.
- To avoid sudden change of temperature while the power is off, you should avoid opening the door. A refrigerator will keep food safe for up to 4 hours during a power outage. Keep the door closed as much as possible. Discard refrigerated perishable food such as meat, poultry, fish, eggs, and leftovers after 4 hours without power.

SAFETY AND WARNINGS

IMPORTANT!

This device complies with part 15 of the FCC Rules. Operation is subject to the following conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.
- Do not change or modify the wireless communication device in any way. Changes or modifications not expressly approved by Fisher & Paykel could void the user's authority to operate the equipment.


WARNING: The incorporated Wi-Fi module in this appliance is to operate only from channel 1 to channel 11 as per FCC rules.

This device contains licence-exempt transmitter /receiver that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.

BEFORE YOU BEGIN

Triple Zone Refrigerator (RS2474S3)




Features

- ① Control panel
- ② Dairy compartment
- ③ Adjustable shelving
- ④ Door shelves
- ⑤ Internal water dispenser*
- ⑥ Bottle holder accessory
- ⑦ Bottle shelf
- ⑧ Humidity control bins
- ⑨ Variable temperature zones
- ⑩ Water filter (not shown)

*Located in inner left side wall of the top compartment.

Triple Zone Freezer (RS2474F3)




Features

- ① Control panel
- ② Pocket shelf
- ③ Adjustable shelving
- ④ Fixed shelves
- ⑤ Bottle holder accessory
- ⑥ Bottle shelf
- ⑦ Variable temperature zones
- ⑧ Automatic ice maker (not shown)*
- ⑨ Freezer bins
- ⑩ Water filter (not shown)

*Located inside freezer bin.

BEFORE YOU BEGIN

Bottom mount refrigerator (RS2474B)




Features

- ① Control panel
- ② Dairy compartment
- ③ Adjustable shelving
- ④ Door shelves
- ⑤ Internal water dispenser*
- ⑥ Bottle holder accessory
- ⑦ Bottle shelf
- ⑧ Humidity control bin
- ⑨ Ice maker (not shown)
- ⑩ Freezer bins
- ⑪ Water filter (not shown)


*Located in inner left side wall of the top compartment.

CONTROL PANEL

Bottom mount Refrigerator Freezer




Triple Zone Refrigerator / Freezer



- | | |
|-------------------------|---|
| ① Menu | Press to access product features and settings, or to return to standby. If the display has been locked, hold for two seconds to unlock. |
| ② Display screen | Displays product features and settings. |
| ③ Scroll | Press to select food modes and adjust temperatures. Enables you to scroll through the menu, features and settings. |
| ④ Select | Press to confirm and activate the selected features and settings. |
| ⑤ Back | Press to go back to the previous menu. |

Install mode

When the product is first delivered it is in Install Mode to help assist installers.



Press and hold  to activate the appliance and display the menu.

FOOD MODES

Variable temperature zones

Separate food modes, in both fridge and freezer, allow you adjust the temperature independently for optimal storage.

| FOOD MODES | DESCRIPTION | TYPES OF FOOD TO STORE |
|-----------------------------------|---|--|
| PANTRY (12°C/54°F) | PANTRY mode provides a cool, dark place for a wide variety of foods that perish quickly or may spoil at room temperature, but are too sensitive to be stored at normal refrigerator temperatures. | Bananas, avocados, tomatoes, tropical fruits, root vegetables. Dry food items such as grains, flours, sugars, crackers, cereal, baked goods, tortillas, wraps and breads. Spreads, preserves, honey, tropical fruits, nuts and seeds, chocolate and fresh herbs. Wine |
| FRIDGE (3°C/37°F) | The ideal mode for fresh, everyday foods. This mode offers a higher relative humidity than many other refrigerators allowing fresh foods such as fruits and vegetables, meats and cheeses to stay fresher for longer. | Fruit and vegetables, dairy products, jams and chutneys/preserves, meats and drinks. |
| CHILL (-0.5°C/31°F) | CHILL mode is an extension of FRIDGE mode, providing the perfect storage zone for highly perishable food to ensure they retain their vital freshness and quality. These items will last slightly longer here compared with storage at FRIDGE mode. | Highly perishable meats, poultry and seafood. Alcoholic beverages such as beer. |
| SOFT FREEZE (-9°C/16°F) | SOFT FREEZE mode is an extension of your refrigerator, extending the shelf life of perishable items while maintaining the quality. SOFT FREEZE mode allows easy portioning of food and the ability to heat, cook or serve foods straight from the compartment without waiting for it to thaw. | Meats, seafood, soups, sauces, pureed foods, bread, desserts and pastries. Soft Freeze mode is not recommended for storage of creamy desserts such as ice cream. |
| FREEZER (-18°C/0°F) | FREEZER mode is for general frozen food items that require storage between 1-12 months. | Meat, poultry, seafood, pre-cooked foods and leftovers, some fruits and vegetable, ice cream, and other frozen desserts. |

Not all food modes available on every model.

Some food modes cannot be used in combination.

FEATURES

| FEATURE | DESCRIPTION |
|---------------------|---|
| ICE | <p>Turns on or off your automatic ice maker in the bottom compartment. Your ice maker is designed to automatically dispense ice into the ice storage bin below until it detects the bin is full. The more ice you use, the more it makes.</p> <p>Before first use the automatic ice system must be flushed. Refer to your install guide for further information.</p> |
| ICE BOOST | <p>Increases ice production and deactivates automatically after 24 hours.</p> |
| MAX COLD | <p>Boosts the cooling speed by dropping a compartment or the whole refrigerator to its coldest temperature for a set time.</p> <p>Durations to comply with: Pantry - 6 hours, fridge - 6 hours, chill - 4 hours, soft freeze - 12 hours & freezer - 24 hours.</p> <p>Use MAX COLD when you are adding food items to your appliance such as after grocery shopping. This feature will ensure your food is chilled or frozen within the shortest period of time, locking in freshness and extending the shelf life of your food.</p> |
| BOTTLE CHILL | <p>Rapidly chills your beverages in the freezer for 15 minutes. Depending on the size of your beverage, the default time may not be enough to chill your beverage. If your beverage is not cold enough after the set time, return it to the compartment and reset the BOTTLE CHILL feature.</p> |
| WATER DISPENSER | <p>Enables you to lock and unlock the water dispenser.</p> |
| DOOR ALARM | <p>Allows you to temporarily stop door alarms. It will automatically disable after 20 minutes or when the doors are closed.</p> |
| DISPLAY LOCK/UNLOCK | <p>Enables you to disable the buttons on the control panel. This is useful when cleaning your appliance.</p> |
| SABBATH | <p>In SABBATH, alarms, lights and displays are deactivated for 80 hours:</p> <ul style="list-style-type: none">• The interior light will not turn on when you open the refrigerator.• The door alarms will not operate.• The display will not illuminate, except the SABBATH.• The control panel will not operate.• Sabbath mode automatically deactivates after 80 hours. <p>If you turn off your refrigerator while in SABBATH, it will resume automatically once the refrigerator is switched on again.</p> |

Not all features available on every model.

SETTINGS

| SETTING | DESCRIPTION |
|--------------------------|---|
| WI-FI SETUP | May enable you to connect to your home wireless network and operate remotely using the app. |
| WATER FILTER TIMER RESET | Enables you to reset the water filter replacement reminders. |
| FORCE ICE FLIP | Enables you to force the ice tray to flip. This is used when flushing the water filter after a vacation or when the filter has been replaced. |
| DISPLAY SOUND | Enables you to silence all control panel sounds. |
| DISPLAY BRIGHTNESS | Enables you to adjust the brightness of the display on the control panel. |
| TEMPERATURE UNITS | Enables you to change the unit of temperature shown on the display screen between Celsius (°C) and Fahrenheit (°F). |
| WATER FILTER REMINDERS | Enables a notification to indicate when the water filter must be replaced. |
| FACTORY RESET | Enables you to reset your appliance to the default factory settings. |

WI-FI CONNECTION

Getting started


Your appliance may be connected to your home wireless network and operated remotely using the app.

- Ensure your home Wi-Fi network is turned on.
- You will be given step by step guidance on both your appliance and mobile device.
- It may take up to 10 minutes to connect your appliance.


On your mobile device:

- ① Download the app from www.fisherpaykel.com/connect
- ② Register and create an account.
- ③ Add your appliance and set up the Wi-Fi connection.

Connecting to Wi-Fi




Press  to display the menu.




Press  or  to scroll through the list and select **SETTINGS**.

Press  to confirm.



Press  or  to scroll through the list and select **WI-FI SETUP**. Press  to confirm.




Follow the prompts on screen and in the app to complete set-up.


ADJUSTING THE TEMPERATURE

Adjusting the temperature from quick access


When you turn on your appliance for the first time, the cooling system will automatically cool all compartments to their default food mode and temperature (Fridge and 3C for refrigerators and Freezer and -18C for freezers). This will take about 2-3 hours. The temperature can be adjusted to user's preference. Follow the steps below to quickly adjust the temperature of the food mode in each compartment.



From the idle screen, press **▼** or **▲** to select the desired compartment.



Press **✓** to confirm the selection.



Press **▼** or **▲** to increase or decrease the temperature.




Press **✓** to confirm.


A confirmation screen will appear and the change will be reflected on the idle screen.

FOOD MODE PRESETS


Food modes have been grouped into preset combinations. Ensure each compartment is running the intended food mode and is appropriate for the foods being stored. Ensure the appropriate food mode has been selected for the food types you wish to store. Refer to 'Food modes' and 'Food care' for information.




Press



Press or to scroll through the list to Food Mode Presets.
Press to confirm.



Press or to scroll through the preset combinations.



Press to select the desired Food Mode combination.




The active Food Mode preset will show first in the list of presets, and be reflected by a dot adjacent to the preset number.



The food mode combination in use will be shown on the idle screen.


CHANGING FEATURES

1




Press  to display the menu.

2



Press  or  to scroll through the list and select the required feature. Press  to confirm.

3



Press  or  to select the desired compartment if applicable for the feature.

4



Press  to activate/deactivate the feature.


CHANGING SETTINGS

1




Press  to display the menu.

2




Press  or  to scroll through the list and locate **SETTINGS**.
Press  to confirm.

3



Press  or  to scroll through the list and locate the desired setting.

4




Press  to change the setting or to enter the setting for more setting options.
Press  to confirm the selection.

WATER DISPENSER

Using the water dispenser (Triple Zone Refrigerator and B model)

The water dispenser is located inside on the left side wall of the top compartment.




To dispense water, gently press the dispensing pad with a glass or container.

To stop the flow of water, simply pull your glass or container away from the dispensing pad.


Pressing hard against the dispensing pad will not increase the flow or dispense more water.

When dispensing water for long durations a time out period may occur. An alarm will sound. Please wait 4 minutes before dispensing again.

Locking/unlocking the water dispenser




Press to display the menu.



Press or to scroll to **WATER DISPENSER**.

Press to lock or unlock the water dispenser.



Press to lock or unlock the water dispenser.

Illustrations may differ from your purchased appliance.

ICE MAKER

Your automatic ice maker will produce ice into the storage bin below. Ice making will continue until the storage bin is full. Ice making will resume once you start to use the stored ice.

On initial start up of your appliance, your ice maker may take several hours to produce ice. This is normal. Please ensure the ice maker feature is turned **ON**. Refer to 'Changing features' for information.

- An ice scoop is provided for hygienic use.

If a large amount of ice is required, remove the storage bin and allow ice to fall into the larger bin. For maximum ice storage, level the stored cubes with the ice scoop.

Empty the ice storage bin periodically discarding any old ice. Wash and dry the storage bin thoroughly and place back into the correct position. Refer to 'Care and cleaning'.

Turn your ice maker off if:

- There is no water supply for several hours.
- You are removing the ice storage bin for a long period of time.
- You are going on holiday/vacation.

STORAGE FEATURES

REFRIGERATOR

Fruits and vegetables bins with humidity control lids

Lids create a humid microclimate by reducing dry air going into the bins. The specially designed grooves retain condensation, keeping humidity high and reduce dripping onto the produce below.

Separate fruits and vegetables to prevent ethylene-sensitive produce from ripening too quickly.

Also used for storing deli items and beverages, or defrosting foods.

Cantilever glass shelving

Heat-treated safety glass.

Can be removed and positioned at heights to suit your storage requirements.

Dairy shelf and door shelves

The top door shelf is a dairy compartment for storing butter and cheeses.

The middle shelves are designed for general items, condiments and drinks.

The bottom shelf is designed to store large drinks or those drinks you require frequent access to.

Shelves are adjustable

Single bottle holders

Can be placed along the length of any shelf to store a variety of bottles.

Store bottles with the neck facing the front of the refrigerator.

FREEZER

Cantilever glass shelving (RS6019F2 and RS6019F3)

Heat-treated safety glass.

Can be removed and positioned at heights to suit your storage requirements.

Door Shelves (RS6019F3)

Designed for general frozen items and alcoholic beverages such as spirits (**FREEZER** and **SOFT FREEZE**) and beer and wine (**CHILL**).

Ice Maker (Ice & Water models only)

Removable ice container. (RS6019BU & RS6019F3 only)

Hygienic ice scoop. (RS6019BU & RS6019F3 only)

Freezer bins

Allow for easy storage of frozen food items.

CARE AND CLEANING

Do not use harsh chemicals, abrasives, ammonia, chlorine, bleach, concentrated detergents, solvents or abrasive scouring pads on any part of your appliance. Some of these chemicals may damage your appliance.

Clean all surfaces with a mild liquid detergent dissolved in warm water and a soft cloth. Rinse with clean water and dry with a clean, lint-free cloth.

Exterior cleaning

Condenser coils

The condenser coils of your appliance requires periodic cleaning by a Fisher & Paykel trained and supported service technician.


Toe kick grilles and filter

We recommend cleaning the grille and filter in conjunction with changing your water filter every 6 months.

- ① To maximize operating efficiency, keep ventilation openings clear of obstructions by regularly vacuuming the flooring in front of your appliance.
- ② More frequent cleaning may be necessary for dusty homes or those with pets shedding hair.

Interior cleaning

Cantilevered glass shelves




To remove, hold the front and back edge of the shelf firmly.

Push the shelf up vertically to dislodge from back support lugs.

Pull the shelf towards you.

Fixed shelf




Pull the shelf towards you to release the clips.

Lift shelf up to remove.


CARE AND CLEANING

Removing the bins

The runners are pre-lubricated to help open and close the bins. Do not remove the grease from the runners to maintain its smooth function. If the bins are not regularly fully extended, the extension of the runners may be reduced. To restore the extension of the runners pull them out.



To remove a bin, extend the bin on its runners, and empty the bin.




Push the securing tabs on both sides of the bin corners, then push the bin firmly upwards to dislodge from the runners.

CARE AND CLEANING


Humidity control lids (Upper Compartment)

①



Remove fixed shelf.


②



Lift the humidity control lid upwards to remove

Humidity control lids (Lower Compartment)

①



Remove the bin.

②



Pull the humidity control lid towards you to release the clip.

③




Lift lid up and slide out to remove.

CLEANING AND CARE


Bin Removal

①




Pull the bin towards you to remove. Push both runners back into the appliance.

②



To return the bin, extend the runners and place the bin on top of the runners.

③



Push the bin slowly onto the securing tabs until you feel it clip onto the runners. Ensure the bin tabs are clipped securely onto the runners before use.

Holiday/vacation (Freezer only)

Before leaving:

Turn the ice maker to **OFF** on the control panel.
Shut off the water supply to the appliance.

On return:

Turn on the ice maker. Discard the first full bin of ice.

FOOD CARE

For best food care

- Store only high-quality, fresh food in your appliance.
- Store perishable foods in the appliance immediately after purchase. Storing at room temperature increases the rate of deterioration and can allow harmful microbial growth.
- Foods such as meat, poultry and seafood should be well wrapped or sealed in suitable packaging to prevent dehydration, color deterioration, loss of flavor, and transfer of odor.

Note: We recommend storing these foods on the bottom shelf of your appliance or in one of the bins to prevent potential spills and cross-contamination with other foods.

- Ensure hot foods and beverages are cooled sufficiently before placing them into the appliance. Hot items may cause other foods to warm to unsafe temperatures. It may also cause sealed items to sweat/condensate — which is undesirable.
- Beverages are best stored standing upright in the door shelves or on the bottle racks provided.
- Ensure raw and cooked foods are stored separately to avoid cross-contamination.
- Consume food items within the recommended storage times. Discard foods that show sign of spoilage.
- Keep door openings to a minimum to maintain optimum storage temperatures inside your appliance.
- We recommend using **MAX COLD** when you are adding food items to your appliance, such as after grocery shopping. This feature will ensure the food is chilled/frozen within the shortest period of time, locking in the freshness and extending the shelf life of your food.
- Storing at temperatures other than the recommended settings may impact the storage life.

Items stored in your refrigerator

- Dairy items such as butter and cheeses should be stored in the covered door shelf to minimize any transfer of odor or odor absorption from other foods.
- Eggs should be stored in their carton to avoid absorption of strong odors through their porous shell structure.
- Fruits & vegetables should be stored in the humidity control bins. These bins provide a humid microclimate to extend the storage times of fruit and vegetables.

Items stored in your freezer

We recommended cooling carbonated beverages only when the **BOTTLE CHILL** function is active.

Do not store carbonated drinks without this function when set to freezer mode. Failure to remove beverages could lead to freezing liquid and the likelihood of bottle/can explosion.

- Ensure air is removed from packaging to avoid large formation of ice crystals and prevent freezer burn.
- To maintain freshness and quality, we recommend defrosting foods in the refrigerator. Ensure partially or fully defrosted foods are never re-frozen — cook immediately.

USER WARNINGS AND SOUNDS

Faults

- In the unlikely event a fault occurs, 4 rapid beeps will be heard and the fault will be displayed on the control panel.
- Record the fault code displayed on the control panel and contact a Fisher & Paykel trained and supported service technician in order to repair the fault. You can do this by going online to fisherpaykel.com or by contacting our Customer Care Center.

Normal appliance sounds

Integrated Refrigerators and Freezers have been designed to have excellent energy ratings and cooling performance. As a result, it can produce sounds somewhat different to your old appliance.

| | |
|---|--|
| Low frequency ticking | This is the valve that controls cooling to each compartment. This noise will only last for a few seconds at a time. |
| Fan air flow | This product has fans which change speed depending on demand. During cooling periods, such as after frequent door openings, fans circulate the cold air in the appliance producing some air flow sound. This is quite normal. |
| Cracking or popping | This may occur when the automatic defrost function is operating. |
| Running water | This is the liquid refrigerant in the system and can be heard as a boiling or gurgling noise. |
| Hissing sound after closing the freezer door | This is due to the pressure difference between the warm air that has entered the cabinet and suddenly cooled, and the outside air pressure. |
| Humming | This is the compressor running and is quite normal. |
| Ice maker noises | Motor operation (low humming). Running water as the ice maker and/or water tank fills. Water valve opening and closing (hissing sound). Loosened from the ice molding tray (cracking). Ice dropping into bin (clunking). |
| Other sounds | Cabinet not stable or level. Bottles or jars rattling on shelves. |

TROUBLESHOOTING

If there is a problem with your appliance, please check the following points before contacting your local Fisher & Paykel trained and supported service technician or the Customer Care Center.

Product parts and accessories can be purchased through the Fisher & Paykel Customer Care Center, or online at fisherpaykel.com (this service is available to selected markets only).

| PROBLEM | POSSIBLE CAUSES | WHAT TO DO |
|-----------------------------------|---|--|
| Appliance does not operate | No electricity at power outlet. | Check that the plug is correctly connected and power switched on. |
| | | Check another appliance at the same outlet. |
| | | Check house breaker. |
| Light not working | Light not functioning. | The lighting cannot be serviced by the user. Contact your Fisher & Paykel dealer or trained and supported service technician. |
| | Appliance not working. | Check appliance is turned on at the wall or at the isolating switch. |
| Light and display not working | Product in SABBATH . | Press  and hold to unlock, scroll to SABBATH and deactivate. |
| Storage compartments too warm | Temperature setting not correct. | Refer to 'Food modes'. |
| | Frequent door openings. | Minimize door openings to allow temperature to stabilize. |
| | Large amount of food has been recently added. | Select MAX COLD to assist in lowering the temperature quickly. |
| Food freezing in the refrigerator | Temperature setting is too cold. | Increase the temperature setting. Refer to 'Adjusting the temperature' and 'Food modes'. |
| | Food placed directly in front of air outlets. | Move chill sensitive foods away from the air outlets. |
| Unfamiliar noises | Cabinet not stable or level. | See Installation guide supplied with this appliance. |
| | Freezer is defrosting. | This is normal. |
| Ice maker sounds | Normal ice maker operation. | Refer to 'User warnings and sounds'. |
| Food Mode is not available | Not all food modes are available in all compartments. | Refer to 'Food mode presets' for available food mode combinations. |

TROUBLESHOOTING

| PROBLEM | POSSIBLE CAUSES | WHAT TO DO |
|--|--|--|
| When the appliance door is opened 4 rapid beeps sound and a code is displayed on the control panel | | Record the code on the control panel and contact Customer Care Center. |
| Water in the vegetable bins | Condensation is generated due to humid environments caused by fruits and vegetables. | Some condensation is beneficial for storage of fruits and vegetables. Wipe out water with a cloth. |
| Condensation/ice inside compartment | Frequent or long door openings. | Minimize door openings. |
| | Door gasket leaking. | Check and clean door gasket seal. |
| | Not unusual during periods of high humidity. | Wipe dry. |
| | Door not closing tightly. | Arrange items in the compartment so door can close tightly. |
| | Doors not aligned. | Call a service technician. |
| Bin does not slide in and out evenly | Packaging trapped. | Check to ensure no food or packaging is trapped behind the tray/bin. |
| Door not closing | An obstruction is blocking door closing. | Move obstruction. |
| | Appliance not installed correctly. | Refer to your Installation guide supplied with this appliance to ensure your appliance has been installed correctly. |
| Freezer door will not open | The door has been recently opened. | Wait 30 seconds and try again. |
| Small or large ice cubes | Water line is kinked/squashed. | Check the external water line is not kinked/squashed. If it is not kinked/squashed contact Customer Care to arrange a technician to check the internal water line. |
| | Blocked water filter. | Change filter before calling technicians. |
| Frozen food items are soft or melting | | Remove items and place in another freezer or cooler and call Customer Care immediately. |
| | Temperature setting not correct. | Adjust the temperature setting. Refer to 'Food modes'. |

TROUBLESHOOTING

| PROBLEM | POSSIBLE CAUSES | WHAT TO DO |
|--|---|--|
| Automatic ice maker does not work | Ice maker has not been turned on. | Switch on ice maker, refer to 'Changing features'. |
| | Water supply turned off or not connected. | Connect the water supply. |
| | Water pressure too low. | Check water pressure. |
| | Water line kinked/squashed. | Check water line for kinks/squashing. |
| | Filter is clogged. | Water filter may need replacing. |
| | Ice cubes clumped in bin. | Remove ice storage bin, loosen cubes and remove clumped ice. Replace ice storage bin. |
| Ice cubes taste tainted | Freezer compartment not working. | Contact Customer Care Center. |
| | Unsealed foods may be transmitting odor/taste. | Discard ice cubes and clean ice storage bin. Refer to 'Interior cleaning'. Wrap or cover strong smelling foods. |
| Ice cubes taste tainted | Poor taste from incoming water. | Replace filter cartridge product parts and accessories can be purchased through our Customer Care Center. |
| | Slow ice cube freezing | Door may have been left ajar. |
| Freezer compartment set too warm. | | Turn temperature to a colder setting. Refer to 'Adjusting the temperature'. |
| Wet ice/ ice clumping | Filter is blocked. | Replace filter cartridge. |
| | Long freezer door openings. | Gently tap ice to unstick or, if large clumps occur, empty ice bin and make new ice. |
| | High ambient temperature. | |
| | Ice bin left out of freezer compartment for a length of time. | |
| Ice will stick together over time. | | |
| Ice is discolored | Water filter has not been flushed. | Refer to your installation guide supplied with your appliance for details on how to flush your water filter. |

SERVICE & WARRANTY

For details of your Manufacturer's Warranty and contacts for servicing, please refer to your separate 'Service & Warranty' book provided with your refrigerator.

This product has been designed for use in a normal domestic (residential environment). This product is not designed for any commercial use. Any commercial use by the customer will affect this products Manufacturer's Warranty.

Complete and keep for safe reference:

| | |
|---------------|-------|
| Model | _____ |
| Serial No. | _____ |
| Purchase Date | _____ |
| Purchaser | _____ |
| Dealer | _____ |
| City | _____ |
| State | _____ |
| Zip | _____ |
| Country | _____ |

FISHERPAYKEL.COM

© Fisher & Paykel Appliances 2022. All rights reserved.

The models shown in this guide may not be available in all markets
and are subject to change at any time.

The product specifications in this guide apply to the specific products and
models described at the date of issue. Under our policy of continuous product
improvement, these specifications may change at any time.

For current details about model and specification availability in your country,
please go to our website or contact your local Fisher & Paykel dealer.

867350A 09.22