


FISHER & PAYKEL

DATA SHEET 24" Oven

Model no:
OB24SCD11PB1, OB24SCD9PB1
(refer page 2 for metric measurements)



| Product Dimensions | in |
|---|----------|
| Ⓐ Overall height of oven | 23 9/16" |
| Ⓑ Overall width of oven | 23 7/16" |
| Ⓒ Depth of front frame (excludes dials, handle and front black stainless trim) | 13/16" |
| Ⓓ Depth of oven chassis and front frame (excludes dials, handle and front black stainless trim) | 22 1/4" |
| Ⓔ Depth of chassis | 21 7/16" |
| Ⓕ Height of chassis | 22 5/8" |
| Ⓖ Width of chassis | 21 7/8" |
| Ⓙ Height from bottom datum to top of oven door | 19 1/16" |
| Ⓚ Height of control panel | 3 15/16" |
| Ⓛ Height of stainless steel strip on control panel | 3/16" |
| Ⓜ Gap between door and control panel | 1/2" |
| Ⓝ Height from bottom datum to centerline of handle | 18 1/4" |
| Ⓞ Width of handle | 22 1/4" |
| Ⓟ Depth of handle (measured from front of door) | 1 5/8" |
| Ⓠ Thickness of handle | 5/8" |
| Ⓡ Distance from bottom of door to bottom of product | 3/8" |
| Ⓢ Depth of door (open) (measured from front of door) | 18 1/8" |

| Minimum Clearances | in |
|----------------------------------|-----------|
| Minimum inside height of cavity: | 22 13/16" |
| Minimum inside width of cavity | 22 1/16" |
| Minimum inside depth of cavity | 21 5/8" |

IMPORTANT NOTE: For full installation and clearance details please refer to our installation manual.

INDICATES PRODUCT DATUM -----
INDICATES CABINETRY CLEARANCES - - - - -

DATE: **21.02.2019**

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com



FISHER & PAYKEL

DATA SHEET 24" Oven

Model no:

OB24SCD11PB1, OB24SCD9PB1

(refer page 1 for imperial measurements)

| Product Dimensions | mm |
|---|-----|
| Ⓐ Overall height of oven | 598 |
| Ⓑ Overall width of oven | 596 |
| Ⓒ Depth of front frame (excludes dials, handle and front black stainless trim) | 20 |
| Ⓓ Depth of oven chassis and front frame (excludes dials, handle and front black stainless trim) | 566 |
| Ⓔ Depth of chassis | 545 |
| Ⓕ Height of chassis | 575 |
| Ⓖ Width of chassis | 556 |
| Ⓗ Height from bottom datum to top of oven door | 485 |
| Ⓙ Height of control panel | 100 |
| Ⓚ Height of stainless steel strip on control panel | 20 |
| Ⓛ Gap between door and control panel | 12 |
| Ⓜ Height from bottom datum to centreline of handle | 464 |
| Ⓝ Width of handle | 565 |
| Ⓟ Depth of handle (measured from front of door) | 42 |
| Ⓠ Thickness of handle | 16 |
| Ⓡ Distance from bottom of door to bottom of product | 10 |
| Ⓢ Depth of door (open) (measured from front of door) | 460 |

| Minimum Clearances | mm |
|----------------------------------|-----|
| Minimum inside height of cavity: | 580 |
| Minimum inside width of cavity | 560 |
| Minimum inside depth of cavity | 550 |

IMPORTANT NOTE: For full installation and clearance details please refer to our installation manual.

INDICATES PRODUCT DATUM -----
INDICATES CABINETRY CLEARANCES - - - - -

DATE: **21.02.2019**

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com

