Tablet Tray Insert

This part replaces 523447 Mid-Gray Tablet Tray for DishDrawer™. Used with dishwasher tablets, place the table on the removable tablet tray. Dishwasher tablets should not be in direct contact with dishes or cutlery. Suits Models: DD60 & DD24.

SKU	511872

TEST The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. ? Fisher & Paykel Appliances Ltd 2020

24/7

A PEACE OF MIND SALE

24 Hours 7 Days a Week Customer Support

T 0800 372 273 **W**www.fisherpaykel.com