QUICK REFERENCE GUIDE > WB24SDEB2

Warming Drawer, 24"

Series 9 | Minimal

Black



Keep plates warm until ready to serve; rapid proof or slow cook to perfection. Pair with an oven for matching Minimal design.

- A companion product, designed to match with other Minimal style Fisher & Paykel products
- Space to keep six standard-sized place settings evenly warm
- Easy to clean smooth-glass base
- Six versatile tailored programmes for warming, proofing, dehydrating and slow cooking

DIMENSIONS

Height	5 1/2
Width	23 7/16
Depth	22 5/16

FEATURES & BENEFITS

Complementary Design

Our Warming Drawer comes in either a stylish black reflective glass or brushed stainless steel, for seamless pairing with our matching ovens.

Multi-Function Flexibility

Choose from six tailored functions including Rapid Proof, Dehydrate and Slow Cook.

Easy To Clean

Cleaning and care of the Warming Drawer is simple. After each use, just wipe out the smooth glass interior with a damp cloth.

Easy To Use

Handle-free, push-to-open with capacitive touch controls, our Warming Drawer gives you the freedom to keep plates or cups warm while you continue to cook.

Precise Control

With fast and even heating, our warming drawer is great for keeping food warm and low temperature cooking, as well as resting after a traditional roast in the oven and proofing dough.

Safe And Sound

With Automatic switch-off and Delayed start functionality, our warming drawers help keep dishes warm until it is time to serve the main meal.

SPECIFICATIONS

Capacity

Cappuccino cups

Espresso cups	42
Maximum allowable weight	55lbs
Place settings	6
Usable depth	16 1/16"
Usable height	3 7/8"
Usable width	21 1/16"

Cleaning

Easy clean smooth-glass base

Controls

Audio feedback	•
Automatic timers	30', 45', 1h, 2h, 4h, 6h
Electronic capacitive touch	•
On/Off indicator	•
Pre-set heating functions	•
Push-to-open drawer	•
Soft close drawer	•
Standby mode	•
	Automatic timers Electronic capacitive touch On/Off indicator Pre-set heating functions Push-to-open drawer Soft close drawer

Functions

Cups	•
Dehydrate	•
Number of functions	6
Plates	•
Slow cook	•
Warm	•

Performance

20

QUICK REFERENCE GUIDE > WB24SDEB2

Heated glass base and fan	•
Low temperature cooking	
Temperature levels	6
Temperature range	95°F-185°F

Power requirements

Amperage	10A
Power outlet	3-prong grounding-type
Supply frequency	60Hz
Supply voltage	110V

Product dimensions

Adjustable front door panel to	
Depth	22 5/16
Height	5 1/2
Width	23 7/16

Safety

Automatic turn off after 12	•
Full extension slides	•

Warranty

Parts and labour	2 years
SKU	82141

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher &

Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. Fisher & Paykel Appliances Ltd 2020

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions.

Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate indicates
carbon emissions from a product's in-use energy. This is calculated either annually
or per cycle, using the product's market-specific energy label energy consumption
data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.

Other product downloads available at fisherpaykel.com



Guide d'utilisation FR



User Guide



Service & Warranty



Installation Guide EN



Guide d'installation FR



Installation Guide Companion Products EN



Data Sheet Warming Drawer



A PEACE OF MIND SALE

24 Hours 7 Days a Week Customer Support

T 1.888.936.7872 **W**www.fisherpaykel.com