





DATA SHEET



30" FREESTANDING GAS RANGE

Model no:
OR30SDBMX1 (refer page 2 for metric measurements)

Dimensions	In
Ⓐ Overall height of range (from floor to cooktop trim, excluding grates and backguard)	35 21/32" - 36 11/32"
Ⓑ Overall width of range	29 7/8"
Ⓒ Overall depth of range (excludes handle and dials)	24 3/16"
Ⓓ Depth from rear of chassis to front datum	24 1/8"
Ⓔ Depth of cooktop trim to front datum	3/32"
Ⓕ Depth of backguard	1 15/16"
Ⓖ Depth of spacers	5/16"
Ⓗ Height of backguard from countertop datum	3"
ⓐ Height from countertop datum to top of grates	1 1/4"
ⓑ Height from bottom of chassis to top of backguard	37 31/32"
ⓔ Height from bottom of chassis to countertop datum	34 31/32"
ⓓ Height from bottom of chassis to bottom of control panel	28 1/16"
ⓖ Height from bottom of chassis to top of oven door	27 1/4"
ⓗ Height from bottom of chassis to top of storage drawer	8 13/16"
Ⓢ Height from bottom of chassis to door handle centerline	25 1/4"
Ⓣ Thickness of handle	29/32"
Ⓤ Width of handle	27 15/16"
Ⓦ Depth of handle to front datum	1 5/8"
Ⓧ Depth of open door to front datum	16 5/16"
Ⓩ Height of adjustable levelling feet	11/16" - 1 3/8"

Minimum Clearances*	in
Overall width of cavity	min 29 7/8"
Overall depth of cavity	max 24 1/8"
Overall height of cavity	35 21/32" - 36 11/32"

* Refer to installation documents for additional cabinetry clearances.




INDICATES PRODUCT DATUM
INDICATES CLEARANCES

DATE: 03.08.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher & Paykel

DATA SHEET



30" FREESTANDING GAS RANGE

Model no:
OR30SDBMX1 (refer page 1 for imperial measurements)

Dimensions	mm
④ Overall height of range (from floor to cooktop trim, excluding grates and backguard)	min 906 max 923
⑥ Overall width of range	759
③ Overall depth of range (excludes handle and dials)	615
⑩ Depth from rear of chassis to front datum	613
⑤ Depth of cooktop trim to front datum	3
⑦ Depth of backguard	50
④ Depth of spacers	8
⑪ Height of backguard from countertop datum	76
① Height from countertop datum to top of grates	32
⑩ Height from bottom of chassis to top of backguard	964
④ Height from bottom of chassis to countertop datum	888
① Height from bottom of chassis to bottom of control panel	713
⑪ Height from bottom of chassis to top of oven door	692
⑪ Height from bottom of chassis to top of storage drawer	224
⑩ Height from bottom of chassis to door handle centreline	642
⑦ Thickness of handle	23
⑥ Width of handle	710
⑥ Depth of handle to front datum	41
③ Depth of open door to front datum	415
① Height of adjustable levelling feet	min 18 max 35

Minimum Clearances*	mm
Overall width of cavity	min 759
Overall depth of cavity	max 613
Overall height of cavity	min 906 - max 923

* Refer to installation documents for additional cabinetry clearances.

INDICATES PRODUCT DATUM -----
INDICATES CLEARANCES -----

DATE: 03.08.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2\text{mm}$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com