

# Warming Drawer, 60cm

Series 9 | Minimal

Black



Keep plates warm until ready to serve; rapid proof or slow cook to perfection. Pair with an oven for matching Minimal styling.

- A companion product, designed to match with other Contemporary style Fisher & Paykel products
- Space to keep six standard-sized place settings evenly warm
- Easy to clean smooth-glass base
- Six versatile tailored programmes for warming, proofing, dehydrating and slow cooking

## DIMENSIONS

Height	140mm
Width	596mm
Depth	567mm

## FEATURES & BENEFITS

### COMPLEMENTARY DESIGN

Our Warming Drawer comes in either a stylish black reflective glass or brushed stainless steel, for seamless pairing with our matching ovens.

### MULTI-FUNCTION FLEXIBILITY

Choose from six tailored functions including Rapid Proof, Dehydrate and Slow Cook.

### EASY TO CLEAN

Cleaning and care of the Warming Drawer is simple. After each use, just wipe out the smooth glass interior with a damp cloth.

### EASY TO USE

Handle-free, push-to-open with capacitive touch controls, our Warming Drawer gives you the freedom to keep plates or cups warm while you continue to cook.

### PRECISE CONTROL

With fast and even heating, our warming drawer is great for keeping food warm and low temperature cooking, as well as resting after a traditional roast in the oven and proofing dough.

### SAFE AND SOUND

With Automatic switch-off and Delayed start functionality, our warming drawers help keep dishes warm until it is time to serve the main meal.

## SPECIFICATIONS

Capacity	20
Cappuccino cups	

Espresso cups	42
Place settings	6
Usable depth	408mm
Usable height	98mm
Usable width	535mm

## Cleaning

- Easy clean smooth-glass base

## Controls

- Audio feedback
- Automatic pre-set
- Automatic timers **30', 45', 1h, 2h, 4h, 6h**
- Delayed start
- Electronic capacitive touch
- On/Off indicator
- Pre-set heating functions
- Push-to-open drawer
- Standby mode

## Functions

- Cups
- Dehydrate
- Number of functions **6**
- Plates
- Slow cook
- Warm

## Performance

Heated glass base and fan	•
Low temperature cooking	•
Temperature levels	6
Temperature range	35°C-85°C

Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

**Power requirements**

Amperage	10A
Power cord length	1800mm
Supply frequency	50Hz
Supply voltage	220V

**Product dimensions**

Adjustable front door panel to	•
Depth	567mm
Height	140mm
Width	596mm

**Safety**

Automatic turn off after 12	•
Full extension slides	•


**Warranty**

Parts and labour	2 years
------------------	---------

SKU	82191
-----	-------

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher &

**Other product downloads available at fisherpaykel.com**

- [↓](#) Restriction of Hazardous Substances
- [↓](#) Restriction of Hazardous Substances
- [↓](#) User Guide 
- [↓](#) Service & Warranty
- [↓](#) Installation Guide
- [↓](#) Data Sheet Warming Drawer



**A PEACE OF MIND SALE**

24 Hours 7 Days a Week Customer Support

T 400 640 8777 **W**www.fisherpaykel.com