



Model no:

DD60DCW9, DD60DCHW9

Dimensions	mm
Ⓐ Overall height* of DishDrawer™	820 - 880
Ⓑ Overall width of DishDrawer™	599
Ⓒ Overall depth of DishDrawer™	573
Ⓓ Depth of chassis	553
Ⓔ Depth of front panel	20
Ⓛ Height of chassis	811
Ⓜ Height of drawer fronts	712
Ⓝ Height of upper front panel	393
Ⓟ Height of lower front panel	312
Ⓠ Height from floor to bottom of lower front panel	100 - 160
Ⓡ Height from top of front panel to top of chassis	8
Ⓢ Ventilation gaps between panels	7
Ⓣ Height of toekick panel	72 - 127
Ⓤ Depth of toekick recess	38 - 54
Ⓡ Height of adjustable levelling feet	9 - 69
Ⓡ Maximum extension of drawer from front datum	547

\* includes mounted feet

Minimum Clearances	mm
Height of cavity	min 820
Width of cavity	600
Depth of cavity	min 560
Minimum clearance from a corner cupboard	13

Note: Service outlet at rear extends both sides, hoses and cords can be routed to either or both.

INDICATES CABINETRY / PRODUCT DATUM -----  
 INDICATES CABINETRY CLEARANCES - - - - -

DATE: 07.09.2016

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit [www.fisherpaykel.com](http://www.fisherpaykel.com)