Warming Drawer, 30"

Series 9 | Minimal

Black



Keep plates warm until ready to serve; rapid proof or slow cook to perfection. Pair with an oven for matching Minimal design.

- A companion product, designed to match with other Minimal style Fisher & Paykel products
- Space to keep 16 standard-sized place settings evenly warm, with accessory rack for optimising space
- Easy to clean smooth-glass base
- Six versatile tailored programmes for warming, proofing, dehydrating and slow cooking

DIMENSIONS

Height	10 11/16″
Width	29 15/16″
Depth	22 5/16″

FEATURES & BENEFITS

Complementary Design

Our Warming Drawer comes in either a stylish black reflective glass or brushed stainless steel, for seamless pairing with our matching ovens.

Multi-Function Flexibility

Choose from six tailored functions including Rapid Proof, Dehydrate and Slow Cook.

Easy To Clean

Cleaning and care of the Warming Drawer is simple. After each use, just wipe out the smooth glass interior with a damp cloth.

Easy To Use

Handle-free, push-to-open with capacitive touch controls, our Warming Drawer comes with an accessory rack for optimising space.

Precise Control

With fast and even heating, our warming drawer is great for keeping food warm and low temperature cooking, as well as resting after a traditional roast in the oven and proofing dough.

Safe And Sound

With Automatic switch-off and Delayed start functionality, our warming drawers help keep dishes warm until it is time to serve the main meal.

SPECIFICATIONS

Accessories

Wire shelf	1
Capacity	
Accessory rack maximum	42lb
Cappuccino cups	24
Espresso cups	54
Maximum allowable weight	55lbs
Place settings	16
Usable depth	16 1/16″
Usable height	9 1/16″
Usable width	27 1/2"

Cleaning

Easy clean smooth-glass base

Controls

Audio feedback	•
Automatic timers	30', 45', 1h, 2h, 4h, 6h
Electronic capacitive touch	•
On/Off indicator	•
Pre-set heating functions	•
Push-to-open drawer	•
Sabbath mode	•
Soft close drawer	•
Standby mode	•

Functions

Cups	•
Dehydrate	•
Number of functions	6

QUICK REFERENCE GUIDE > WB30SDEB1

Plates	•	SKU
Slow cook	•	
Warm	•	

Performance

Heated glass base and fan	•
Low temperature cooking	•
Temperature levels	6
Temperature range	95°F-185°F

Power requirements

Amperage	10A
Power outlet	3-prong grounding-type
Supply frequency	60Hz
Supply voltage	110V

Product dimensions

Adjustable front door panel to	•
Depth	22 5/16"
Height	10 11/16″
Width	29 15/16″

Safety

Automatic turn off after 12

Full extension slides

Warranty

Parts and labor

2 years

82113

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher &

Paykel's Customer Care Centre to ensure this page correctly describes the model

All appliances use energy, and energy usage typically generates carbon emissions. **Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate** indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption

data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy

currently available. Fisher & Paykel Appliances Ltd 2020

Carbon Emissions Estimate than a vented dryer.

Where applicable:

Other product downloads available at fisherpaykel.com

<u> </u>	User Guide
<u>+</u>	Guide d'utilisation FR
<u>+</u>	Service & Warranty
<u>+</u>	Installation Guide
<u>+</u>	Data Sheet Warming Drawer

