

FISHER & PAYKEL

DATA SHEET

76cm Oven

Model no: OB76SDPTDB1

Product Dimensions	mm
Overall height of oven	690
Overall width of oven	760
\odot Depth of front frame (excludes handle, front black aluminium trim and dial)	40
 Depth of oven chassis and front frame (excludes handle, front black aluminium trim and dial) 	609
Depth of chassis	569
F Height of chassis	675
⑥ Width of chassis	720
(#) Height of control panel	100
I) Height of black aluminium trim on control panel	20
④ Height from bottom datum to top of oven door	578
(8) Height from bottom datum to centerline of handle	553
() Height from bottom datum to bottom of door	28
Width of handle	727
® Depth of handle	42
③ Thickness of handle	13
 Depth of door (open) (measured from front of door) 	550

Minimum Clearances	mm
Minimum inside height of cavity	681
Minimum inside width of cavity	724
Minimum inside depth of cavity (proud installation*)	575

*Flush installation possible. Depending on cabinet panel thickness a rebate around front frame might be required, refer Installation Manual.

IMPORTANT NOTE: For full installation and clearance details please refer to our installation manual.

INDICATES PRODUCT DATUM ----INDICATES CABINETRY CLEARANCES ------

DATE: 31.10.2019

G

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com