
DATA SHEET



790MM ACTIVESMART™ FRIDGE - FRENCH DOOR

Product Dimensions	mm
Overall height* of fridge	1715
Overall width of fridge	790
© Depth of fridge door and gasket (excludes handle)	70
 Depth of fridge door and chassis (excludes handle) 	695
Depth of fridge chassis (does not include fridge door)	625
© Height from bottom datum to top of fridge door	1691
© Height of feet (adjustable)	24
Height from bottom datum to top of top handle	1333
① Height from bottom datum to bottom of top handle	691
 Height from bottom datum to bottom of top door 	636
Beight from bottom datum to top of bottom door	622
Height from bottom datum to centreline of bottom handle	559
Thickness of handles	16
 M Height from bottom datum to bottom of bottom door 	16
 Depth of handle (measured from front of door) 	41
Depth of door (open at 90°) (measured from front of door)	350
 Depth of drawer (open) (measured from front of drawer) excluding handle 	375
Rotation of door (open)	138°

mm
1735
20
135
30

INDICATES PRODUCT DATUM ----INDICATES CABINETRY CLEARANCES ------

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2mm$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com

Fisher&Paykel _