



Product Dimensions	in
<ul> <li>Ø Overall height* of oven</li> </ul>	27 1/8"
Overall width of oven	29 29/32"
${\ensuremath{}}$ ${\ensuremath{}}$ ${\ensuremath{}}$ of oven front and control panel** (excludes handle and dials)	1 17/32"
Depth of oven chassis (does not include oven front)	22 13/32"
E Height from bottom datum to top of stainless fascia cap	24 3/16"
🕞 Height from bottom datum to bottom of stainless fascia cap	22 13/32"
Iteight from bottom datum to top of door	21 15/16"
Height from bottom datum to top of handle	20 29/32"
① Height from bottom datum to bottom of handle	20 9/32"
<ul> <li>④ Height from bottom datum to top of stainless door cap</li> </ul>	4 11/16"
® Height from bottom datum to top of vent	1 5/32"
U Height of chassis	26 9/16"
Depth of door (open) (measured from front of door)	20 7/8"
Overall width of chassis	28 11/32"
◎ Width of handle	28 5/8"
P Depth of handle (measured from front of door)	1 21/32"

\* All height measurements included mounted feet


\*\* Measured to front glass surface and excludes 3/32" stainless cap

Minimum Clearances	in
Height of cavity from bottom datum	26 13/16"
Minimum inside width of cavity	28 1/2"
Minimum inside depth of cavity from front datum	22 5/8"



DATE: 04.04.2016

IMPORTANT NOTE: Throughout this guide, dimensions may vary by  $\pm 2mm$  (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com



Ø

## Fisher&Paykel \_\_\_\_\_



Model no: OB30SDEPX3 OB30SCEPX3 (refer page 1 for imperial measurements)

Product Dimensions	mm
Overall height* of oven	689
Overall width of oven	760
$\fbox{\sc c}$ Depth of oven front and control panel** (excludes handle and dials)	39
Depth of oven chassis (does not include oven front)	569
(E) Height from bottom datum to top of stainless fascia cap	614
🕞 Height from bottom datum to bottom of stainless fascia cap	569
I Height from bottom datum to top of door	557
Height from bottom datum to top of handle	531
① Height from bottom datum to bottom of handle	515
④ Height from bottom datum to top of stainless door cap	119
Height from bottom datum to top of vent	29
© Height of chassis	675
Depth of door (open) (measured from front of door)	530
N Overall width of chassis	720
③ Width of handle	727
Depth of handle (measured from front of door)	42

\* All height measurements included mounted feet


\*\* Measured to front glass surface and excludes 2mm stainless cap

Minimum Clearances	
Height of cavity from bottom datum	681
Minimum inside width of cavity	724
Minimum inside depth of cavity from front datum	575



DATE: 04.04.2016

IMPORTANT NOTE: Throughout this guide, dimensions may vary by  $\pm 2mm$  (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com



۵

200

400 Millimetre: