
DATUM: FRONT OF CHASSIS PLAN VIEW



FISHER & PAYKEL

DATA SHEET 24" Oven

Model no:

OB24SDPTDB1

(refer page 2 for metric measurements)

| Product Dimensions | in |
|--|----------|
| Overall height of oven | 23 9/16" |
| Overall width of oven | 23 7/16" |
| © Depth of front frame (excludes dial, handle and front metal trim) | 13/16" |
| Depth of oven chassis and front frame (excludes dial, handle and front metal trim) | 22 1/4" |
| © Depth of chassis | 21 7/16" |
| Height of chassis | 22 5/8" |
| Width of chassis | 21 7/8" |
| Height from bottom datum to top of oven door | 19 1/8" |
| ① Height of control panel | 3 15/16" |
| Height of metal cap on control panel | 13/16′′ |
| Height from bottom datum to centerline of handle | 18 1/4" |
| © Width of handle | 22 1/4" |
| Depth of handle (measured from front of door) | 1 5/8" |
| N Thickness of handle | 5/8" |
| Height from bottom datum to bottom of door | 3/8" |
| Depth of door (open) (measured from front of door) | 18 1/8" |

| Minimum Clearances | in |
|---------------------------------|-----------|
| Minimum inside height of cavity | 22 7/8" |
| Minimum inside width of cavity | 22 1/16" |
| Minimum inside depth of cavity | 21 11/16" |


IMPORTANT NOTE: For full installation and clearance details please refer to our Installation Manual.

INDICATES PRODUCT DATUM -----INDICATES CABINETRY CLEARANCES ------

DATE: 11.12.2019

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com

DATUM: FRONT OF CHASSIS PLAN VIEW



FISHER & PAYKEL

DATA SHEET 24" Oven

Model no:

OB24SDPTDB1

(refer page 1 for imperial measurements)

| Product Dimensions | |
|--|-----|
| Overall height of oven | 598 |
| Overall width of oven | 596 |
| © Depth of front frame (excludes dial, handle and front metal trim) | 20 |
| Depth of oven chassis and front frame (excludes dial, handle and front metal trim) | 565 |
| © Depth of chassis | 545 |
| Height of chassis | 575 |
| Width of chassis | 556 |
| Height from bottom datum to top of oven door | 485 |
| ① Height of control panel | 100 |
| Height of metal cap on control panel | 20 |
| Height from bottom datum to centerline of handle | 464 |
| © Width of handle | 565 |
| ⊕ Depth of handle (measured from front of door) | 42 |
| N Thickness of handle | 16 |
| Height from bottom datum to bottom of door | 10 |
| Depth of door (open) (measured from front of door) | 460 |
| | |

| Minimum Clearances | mm |
|---------------------------------|-----|
| Minimum inside height of cavity | 580 |
| Minimum inside width of cavity | 560 |
| Minimum inside depth of cavity | 550 |

IMPORTANT NOTE: For full installation and clearance details please refer to our Installation Manual.

INDICATES PRODUCT DATUM -----INDICATES CABINETRY CLEARANCES ------

DATE: 11.12.2019

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com