



Model no:

RF306RDWX1

Dimensions	mm
Ⓐ Overall height* of wine cabinet	1660
Ⓑ Overall width of wine cabinet	595
Ⓒ Depth of wine cabinet door and gasket (excludes handle)	60
Ⓓ Overall depth of wine cabinet (excludes handle)	639
Ⓔ Depth of wine cabinet chassis (does not include door)	579
Ⓕ Height from bottom datum to top of wine cabinet	1630
Ⓖ Height of feet (adjustable)	30
Ⓗ Height from bottom datum to bottom of door	40
Ⓘ Height from bottom datum to bottom of handle	150
Ⓢ Height from bottom datum to top of handle	1530
Ⓚ Width of handle	17
Ⓛ Depth of handle (measured from front of door)	51
Ⓛ Distance from left edge of wine cabinet to centre of handle	27.5
Ⓝ Depth of door (widest opening) measured from front of door	560
Ⓒ Minimum door clearance to adjacent wall (full door rotation)	225

* Includes mounted feet

Clearances Dimensions	mm
Overall height of cavity	1710
Overall width of cavity	635
Overall depth of cavity - to chassis (proud install)	612
Overall depth of cavity - to flat door (flush install)	669

INDICATES PRODUCT DATUM
INDICATES CLEARANCES

DATE: 10.07.2015

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2\text{mm}$ (3/32"). Please read the installation manual for detailed information on installing the product. www.fisherpaykel.com