

60cm Series 9 Minimal Warming Drawer

Minimal




Serve meals hot and directly from a pre-heated plate thanks to our panel-ready, warming drawer.

- Integrates with surrounding cabinetry for a seamless look
- Space to keep 16 standard-sized place settings evenly warm, with accessory rack for optimising space
- Easy to clean smooth-glass base
- Six versatile tailored programmes for warming, proofing, dehydrating and slow cooking

DIMENSIONS

Height	290 mm
Width	596 mm
Depth	567 mm



FEATURES & BENEFITS

- Complementary Design**
Our Warming Drawer comes with the option of a stylish black glass panel or elegant grey glass panel, for seamless pairing with our Minimal or Contemporary style ovens.
- Multi-Function Flexibility**
Choose from six tailored functions including Rapid Proof for proofing dough, Dehydrate for drying foods such as meat, fruit and herbs and Slow Cook, ideal for finishing of seared meats, casseroles, stews and braises.
- Precise Control**

With fast and even heating, our warming drawer is great for keeping food warm and low temperature cooking. You can even rest meat after a traditional roast in the oven and proof dough for bread making and pizza.

Added Convenience
Handle-free, push-to-open with intuitive touch controls, our warming drawer gives you the freedom to keep plates or cups warm while you continue to cook.

Easy To Clean
Cleaning and care of the warming drawer is simple. After each use, just wipe out the smooth glass interior with a damp cloth.

Safe And Sound
With automatic switch-off and delayed start functionality, our warming drawers help keep dishes warm until it is time to serve the main meal.

Sized To Suit
With enough room to gently heat 16 place settings, 20 cappuccino cups or 42 espresso cups, our tall warming drawer is an ideal kitchen companion.

SPECIFICATIONS

Accessories (included)	
Wire shelf	1
Capacity	
Accessory rack maximum allowable weight	19kg
Cappuccino cups	20
Espresso cups	42
Maximum allowable weight	25 kg
Place settings	16
Usable depth	408 mm
Usable height	237 mm
Usable width	535 mm

Cleaning		
Easy clean smooth-glass base		•
Controls		
Audio feedback		•
Automatic pre-set temperatures		•
Automatic timers	30', 45', 1h, 2h, 4h, 6h	
Delayed start		•
Electronic capacitive touch controls		•
On/Off indicator		•
Pre-set heating functions		•
Push-to-open drawer		•
Standby mode		•
Functions		
Cups		•
Dehydrate		•
Number of functions	6	
Plates		•
Rapid proof		•
Slow cook		•
Warm		•
Performance		
Heated glass base and fan		•
Low temperature cooking		•
Temperature levels	6	
Temperature range	35°C-85°C	

Power requirements		
Amperage		10 A
Power cord length		1800 mm
Power outlet		3-prong grounding-type
Supply frequency		50 Hz
Supply voltage		220-240 V

Product dimensions		
Adjustable front door panel to align with surrounding cabinetry		•
Depth		567 mm
Height		290 mm
Width		596 mm

Safety		
Automatic turn off after 12 hours		•
Full extension slides		•
SKU		84228

The product dimensions and specifications in this page apply to the specific product and model. Under our policy of continuous improvement, these dimensions and specifications may change at any time. You should therefore check with Fisher & Paykel's Customer Care Centre to ensure this page correctly describes the model currently available. © Fisher & Paykel Appliances Ltd 2020

Other product downloads available at fisherpaykel.com

- [↓](#) DXF
- [↓](#) Archicad

- [↓](#) Declaration of Conformity (English)
- [↓](#) DWG
- [↓](#) Installation Guide (Danish)
- [↓](#) Installation Guide (German)
- [↓](#) Installation Guide (Dutch)
- [↓](#) Installation Guide (English)
- [↓](#) Installation Guide (English)
- [↓](#) Installation Guide (Finnish)
- [↓](#) Installation Guide (French)
- [↓](#) Installation Guide (Hebrew)
- [↓](#) Installation Guide (Italian)
- [↓](#) Installation Guide (Norwegian)
- [↓](#) Installation Guide (Swedish)
- [↓](#) Planning Guide (German)
- [↓](#) Planning Guide - 60cm Minimal Ovens and Companions (English)
- [↓](#) Planning Guide - 60cm Minimal Ovens and Companions (English)
- [↓](#) Planning Guide - Handleless Ovens and Companions (English)
- [↓](#) Planning Guide - Handleless Ovens and Companions (English)
- [↓](#) Revit
- [↓](#) Rhino
- [↓](#) SketchUp
- [↓](#) User Guide (Danish)
- [↓](#) User Guide (German)
- [↓](#) User Guide (Dutch)
- [↓](#) User Guide (English)
- [↓](#) User Guide (English)
- [↓](#) User Guide (Finnish)
- [↓](#) User Guide (French)
- [↓](#) User Guide (Hebrew)
- [↓](#) User Guide (Italian)
- [↓](#) User Guide (Norwegian)
- [↓](#) User Guide (Swedish)

Where applicable:

All appliances use energy, and energy usage typically generates carbon emissions. Fisher & Paykel Appliances' In-use Energy Carbon Emissions Estimate indicates carbon emissions from a product's in-use energy. This is calculated either annually or per cycle, using the product's market-specific energy label energy consumption data multiplied by the carbon emissions factor for energy in your country or region.

Our In-use Energy Carbon Emissions Estimate is designed to assist customers in making informed purchasing decisions when comparing different Fisher & Paykel products. For example, a heat pump dryer typically has a lower In-use Energy Carbon Emissions Estimate than a vented dryer.



A PEACE OF MIND SALE
24 Hours 7 Days a Week Customer Support
T +65 6741 0777 W www.fisherpaykel.com