

FISHER & PAYKEL

DATA SHEET

905mm ActiveSmart[™] Refrigerator - Quad Door

Model no:

RF605QDUVX1, RF203QDUVX1

(refer page 2 for metric measurements)


Product Dimensions	in
Overall height* of fridge	70 1/2"
Overall width of fridge	35 5/8"
© Depth of fridge door and gasket (excludes handle)	3 1/16″
Depth of fridge door and chassis (excludes handle)	27 1/16″
© Depth of fridge chassis (does not include fridge door)	24″
🖲 Height of from bottom datum to bottom of bottom door	1 3/4"
Height of feet (adjustable)	1 3/16"
() Height from bottom datum to top of chassis	69 1/16″
I Height from bottom datum to top of hinge cover	69 7/8"
④ Height from bottom datum to top of top handle	59 15/16"
🛞 Height from bottom datum to bottom of top handle	33 7/16"
© Height from bottom datum to top of bottom handle	31 3/8″
⊗ Height from bottom datum to bottom of bottom handle	18 11/16″
Neight from bottom datum to top of bottom door	32 3/16"
◎ Gap between top and bottom doors	1/2"
⑦ Thickness of handles	5/8″
③ Depth of handle (measured from front of door)	1 5/8″
® Depth of door (open at 90°) (measured from front of door)	15 9/16″
© Rotation of door (open)	130°

* Includes mounted feet

in
71 1/4"
13/16″
3 15/16"
1 3/16"
13 3/8"

DATE: 16.10.2017

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit www.fisherpaykel.com



FISHER & PAYKEL

DATA SHEET

905mm ActiveSmart[™] Refrigerator - Quad Door

Model no:

RF605QDUVX1, RF203QDUVX1

(refer page 1 for imperial measurements)

Product Dimensions	mm
Overall height* of fridge	1790
Overall width of fridge	905
© Depth of fridge door and gasket (excludes handle)	78
Depth of fridge door and chassis (excludes handle)	688
E Depth of fridge chassis (does not include fridge door)	610
E Height of from bottom datum to bottom of bottom door	44
Height of feet (adjustable)	30
(#) Height from bottom datum to top of chassis	1754
① Height from bottom datum to top of hinge cover	1775
 Height from bottom datum to top of top handle 	1522
\otimes Height from bottom datum to bottom of top handle	850
Height from bottom datum to top of bottom handle	798
Height from bottom datum to bottom of bottom handle	474
® Height from bottom datum to top of bottom door	818
 Gap between top and bottom doors 	13
 P Thickness of handles 	16
O Depth of handle (measured from front of door)	41
® Depth of door (open at 90°) (measured from front of door)	396
 S Rotation of door (open) 	130°

* Includes mounted feet

mm
1810
20
100
340

INDICATES PRODUCT DATUM -----INDICATES CABINETRY CLEARANCES ------

DATE: 16.10.2017

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit www.fisherpaykel.com