# 0 POWER OUTLET LOCATION O Θ 0 0 PLAN VIEW 0 **B** 596 **3** 545 0 0 0 0 • 0 **A** 598 DATUM : BOTTOM OF CHASSIS 0 FRONT VIEW PROFILE VIEW 0

# FISHER & PAYKEL

## DATA SHEET Oven, 60cm

Model no:

#### OB60SM16PLG1, OB60SM16PLB1

Product Dimensions	mm
Overall height of oven	598
® Overall width of oven	596
<ul> <li>Depth of front frame (excludes dial, handle and front stainless trim)</li> </ul>	20
Depth of oven chassis and front frame (excludes dial, handle and front stainless trim)	565
© Depth of chassis	545
Height of chassis	575
Width of chassis	556
Height from bottom datum to top of oven door	487
Height from bottom datum to bottom of door	12
Height of control panel	100
® Gap between door and control panel	11
Height from bottom datum to centerline of handle	464
Width of handle     ■ Width of hand	565
Depth of handle (measured from front of door)	42
Thickness of handle	16
Depth of door when open (measured from front of door)	460

Minimum Clearances	mm
Minimum inside height of cavity	580
Minimum inside width of cavity	560
Minimum inside depth of cavity	550

 $\label{lem:model} \mbox{IMPORTANT NOTE: For full installation and clearance details please refer to the installation guide.}$ 

INDICATES PRODUCT DATUM -----INDICATES CABINETRY CLEARANCES ------

### DATE: 08.08.2022

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com