


FISHER & PAYKEL

DATA SHEET 600mm Oven

Model no:

OB60SD11PX1, OB60SD10PX1, OB60SD9PX1, OB60SD7PX1, OB60SD9X1



Product Dimensions	mm
Ⓐ Overall height of oven	598
Ⓑ Overall width of oven	596
Ⓒ Depth of oven frame and door (excludes dials, handle and front stainless trim)	20
Ⓓ Depth of oven door and chassis (excludes handle and front stainless trim)	565
Ⓔ Depth of chassis	545
Ⓕ Height of chassis	575
Ⓖ Width of chassis	556
Ⓗ Height from bottom datum to top of oven door	461
Ⓘ Height of control panel	100
Ⓚ Height of stainless steel strip on control panel	20
Ⓛ Height of stainless steel strip on door	108
Ⓚ Gap between door and control panel	12
Ⓜ Height from bottom datum to centreline of handle	464
Ⓝ Width of handle	565
Ⓞ Depth of handle (measured from front of door)	41
Ⓟ Thickness of handle	16
Ⓠ Distance from bottom of door to bottom of product	9
Ⓡ Depth of door (open) (measured from front of door)	460

Minimum Clearances	mm
Minimum inside height of cavity:	580
Minimum inside width of cavity	560
Minimum inside depth of cavity	550

IMPORTANT NOTE: For full installation and clearance details please refer to our installation manual.

INDICATES PRODUCT DATUM -----
INDICATES CABINETRY CLEARANCES - - - - -

DATE: **26.02.2019**

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2\text{mm}$ (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com

