

FISHER & PAYKEL

DATA SHEET 76cm Single Pro Wall Oven

Model no:
OB76SPPTX1

Product Dimensions	mm
Ⓐ Overall height of oven	689
Ⓑ Overall width of oven	757
Ⓒ Depth of front frame (excludes handle)	39
Ⓓ Depth of oven chassis and front frame (excludes handle)	608
Ⓔ Depth of chassis	569
Ⓕ Height of chassis	675
Ⓖ Width of chassis	719
Ⓗ Height of control panel	100
Ⓘ Height from bottom datum to top of oven door	574
Ⓚ Height from bottom datum to centerline of handle	551
Ⓛ Height from bottom datum to bottom of door	26
Ⓜ Thickness of handle (excluding standoffs)	25
Ⓝ Width of handle (including standoffs)	735
Ⓟ Depth of handle (including standoffs)	58
Ⓠ Depth of door (open) (measured from front of door)	550

Minimum Clearances	mm
Minimum inside height of cavity	681
Minimum inside width of cavity	724
Minimum inside depth of cavity (proud installation*)	575





*Flush installation possible. Depending on cabinet panel thickness a rebate around front frame might be required, refer Installation Manual.

IMPORTANT NOTE: For full installation and clearance details please refer to our installation manual.

INDICATES PRODUCT DATUM -----
INDICATES CABINETRY CLEARANCES - - - - -

DATE: **14.03.2022**

IMPORTANT NOTE: Throughout this guide, dimensions may vary by $\pm 2\text{mm}$ (1/16"). Please read the installation manual for detailed information on installing the product. For full installation instructions & specifications visit fisherpaykel.com



DATUM: FRONT OF CHASSIS