



Model no:  
**RF730QZUVB1**

Product Dimensions	mm
Ⓐ Overall height of fridge	1900
Ⓑ Overall width of fridge	905
Ⓒ Depth of fridge door and gasket (excludes handle)	88
Ⓓ Depth of fridge door and chassis (excludes handle)	748
Ⓔ Depth of fridge chassis (does not include fridge door)	660
Ⓕ Height from bottom datum to top of fridge door	1854.5
Ⓖ Height of feet (adjustable)	45
Ⓗ Height of top door	1067.5
Ⓘ Height of bottom door	771.5
Ⓚ Distance between top and bottom door panels	15.5
Ⓛ Distance between left and right door panels	10
Ⓛ Depth with door open - from rear of fridge - 90° rotation	1142

Minimum Clearances	mm
Overall Internal Height	
• Proud	1920
• Flush	1945
Overall Width	
• Proud	945
• Flush	1125
Overall Depth	
• Proud	690
• Flush	778
Door Clearance to Side Wall	
• Proud	350
• Flush	260

INDICATES PRODUCT DATUM -----  
INDICATES CABINERY CLEARANCES - - - - -

DATE: 30.09.21

IMPORTANT NOTE: Throughout this guide, dimensions may vary by ±2mm (3/32"). Please read the installation manual for detailed information on installing the product. [www.fisherpaykel.com](http://www.fisherpaykel.com)

