

Haier

air conditioners
Wi-Fi

Turn off the air conditioner



Haier

air conditioners
Wi-Fi

Isolate the power



Haier

air conditioners
Wi-Fi

Open the front panel,
lock panel into position



Haier

air conditioners
Wi-Fi

Remove screw and cover.



Haier

air conditioners
Wi-Fi

Pull out lead terminal



Haier

air conditioners
Wi-Fi

Connect WiFi module
to lead terminal.



Haier

air conditioners
Wi-Fi


Recess module between
pcb and fascia edge.



Haier

air conditioners
Wi-Fi

Screw module to receptacle



Haier

air conditioners
Wi-Fi

Connect power and
test WiFi function



Haier
air conditioners
Wi-Fi

Replace cover



Haier
air conditioners
Wi-Fi

Close front panel

